



Key	Part No.	Description
01	165661-000	Receiver Assembly
02	165608-000	Bolt Assembly
03	131443-000	Retaining Pin
04	164731-000	Valve Body Assembly
05	131220-000	Valve Set Screw
06	134447-000	Valve Stem Assembly
07	130811-000	Valve Guide
08	131104-000	Valve Spring
09	164480-000	Valve Plug Assembly
10	165700-000	Barrel Assembly
11	164475-000	Striker Assembly
12	131105-000	Striker Spring
13	131113-000	Spacer
14	131559-000	Spring Guide
15	131081-000	Bumper
16	131560-000	Striker Plug
17	164476-000	Velocity Adjustment Screw
18	131032-000	Ball Stop
19	131033-000	Ball Stop Cover
20	130743-000	Ball Stop Screws
21	164473-000	Braided Hose Assembly

22	131951-000	Cocking Pin
23	131087-000	Bottomline Screw
24	134262-000	Bottomline Adapter
25	130727-000	Filter
26	165607-000	Grip Frame Assembly
27	130806-000	Lock Washer
28	130815-000	Retaining Screw